ORIFICE, TUBE & HOSE REPAIR FITTINGS

GM Orifice 1/2" Tube Repair Kit

Repairs liquid line. Install a new serviceable orifice tube at the evaporator, without replacing the complete line. (Orifice tube extra)



FMSI #5256

Ford Spring Lock Orifice 1/2" Tube Repair Kit

Repairs liquid line. Install a new serviceable orifice tube, without replacing the complete line. (Orifice tube extra)



FMSI #5269

GM/Ford Orifice 1/2" Tube Repair Kit

Repairs liquid line. Install a new serviceable orifice tube, without replacing the complete



FMSI #5270

GM Truck Orifice Tube Repair Kit & Lower Condenser Repair Line

88-98 GM - C, K, Tahoe & Suburban W/M20 X 1.5 tube nut fitting



FMSI #5359

R-134a Low Side "T" Splice Service Port



FMSI # SIZE 5279 10mm 5280 12mm 5281 1/2" 5/8" 5282 3/4" 5283

R-134a High Side "T" Splice Service Port



FMSI # SIZE 5284 8mm 3/8" 5285 5286 10mm 5287 12mm 5288 1/2"

"T" Tap Fittings for Add-on Air Conditioning



FMSI # SIZE 5271 3/8" 1/2" 5272 5/8" 5273 3/4" 5274

GM Truck Upper Condenser Repair Line



R134a REFRIGERANT BARRIER HOSE & FITTINGS

Hose Lok Fitting

FMSI # SIZE 5471 5/16" tube to #6 hose 5248 3/8" tube to #6 hose 5249 1/2" tube to #8 hose 5250 5/8" tube to #10 hose

R134a A/C BARRIER HOSE



For R134a, R12, REPLA 134, and other mobile refrigerants 25 Foot

Coil

AR516 #6 - 5/16" AR1332 #8 - 13/32" #10 - 1/2" AR12 AR58 #12 - 5/8"

Hybrid Hose Lok Fitting



FMSI # SIZE

5473

5251

5/8" tube to #12 hose

3/4" tube to #12 hose

45° Hose Lok Fitting



FMSI # SIZE 5370 3/8" tube to #6 hose 1/2" tube to #8 hose 5371 5372 5/8" tube to #10 hose 5373 3/4" tube to #12 hose

Metric Hose Lok Fitting



FMSI # SIZE

5474 10mm tube to #6 hose 15mm tube to #10 hose 5475 5476 14mm tube to #10 hose 5356 12mm tube to #8 hose

90° Hose Lok Fitting





FMSI # SIZE 5360 3/8" tube to #6 hose 1/2" tube to #8 hose 5361 5/8" tube to #10 hose 5362 5363 3/4" tube to #12 hose