

ORIFICE TUBES & REPAIR KITS



FMSI #5000



Red Evaporator Mounted (.062")
Ford Cars '97-'05, Ford Cars '93, Ford Trucks '86-'05, Mazda '98-2000, Mazda '91, '92, '94

FMSI #5086



Purple Condenser Mounted (.062")
Chrysler Cars '90-'92, Dodge Trucks '94-'04, Eagle '88-'92

FMSI #MT1243



Black Evaporator Mounted (.072")
Ford Trucks '02-'05

FMSI #5001



Green Evaporator Mounted (.052")
Ford Cars '94-'97, Mazda '98-2000

FMSI #5087



Yellow Evaporator Mounted (.062")
Audi '92-'04, GM Cars '97-'05, GM Trucks '98-2000, '02-'05

FMSI #MT1244



Orange Condenser Mounted (.057")
Jeep '93-'05

FMSI #5002



Orange Evaporator Mounted (.057")
Dodge Trucks 2000-'04, Ford Cars '84-'05, Ford Trucks '88-'97, '01-'05, Hyundai '89-2000, Jeep 2000-'05, Nissan '93-2000

FMSI #5088



Yellow Condenser Mounted "T" Top Style (.062")
GM Cars '98-'04, GM Trucks '96-'05

FMSI #MT1245



Yellow Evaporator Mounted (.062")
Volvo '83-2000

FMSI #5003



Black/White Condenser Mounted (.072")
GM Cars '87-'05, GM Trucks '90-'05

FMSI #5089



Orange Condenser Mounted (.057")
Geo Cars '98-2000

SEVERE DUTY VARIABLE ORIFICE TUBES

FMSI #MT0628



Condenser Mounted
GM Cars '87-'05, GM Trucks '90-'05, Jeep '93-'05

FMSI #5004



White Evaporator Mounted (.072")
GM Cars '73-'05, GM Trucks '75-'05

FMSI #5090



Grey (PPOT) (.062")
GM Cars '99-'05

FMSI #MT0629



Evaporator Mounted
Audi '85-'05, Chrysler '90-'92, Dodge Trucks '94-'04, Ford Cars & Trucks '80-'05, Geo '98-2000, GM Cars & Trucks '73-'05, Hyundai '89-2000, Jeep '97-'05, Mazda '91-'02, Nissan '93-2000, Volkswagen '87-'93, Volvo '83-2000

FMSI #5023



Blue Evaporator Mounted (.067")
Ford Cars '80-'01, Ford Trucks '80-'86, '90-'05, Mazda '93-97, Nissan '93-2000

FMSI #5092



Grey Evaporator Mounted (.067")
Audi '85-'93, Volkswagen '87-'93

FMSI #MT0630



Condenser Mounted
GM Cars '87-'05, GM Trucks '90-'05, Jeep '93-'05

FMSI #5085



Brown Evaporator Mounted (.047")
Ford Trucks '86-'97

FMSI #5093



Yellow Evaporator Mounted (.062")
GM Cars '97-'05

FMSI #MT0631



Evaporator Mounted
Audi '85-'05, Chrysler '90-'92, Dodge Trucks '94-'04, Ford Cars & Trucks '80-'05, Geo '98-2000, GM Cars & Trucks '73-'05, Hyundai '89-2000, Jeep '97-'05, Mazda '91-'02, Nissan '93-2000, Volkswagen '87-'93, Volvo '83-2000

Orifice Tube Repair Kits



FMSI #5094
GM-Ford
Evaporator Inlet



FMSI #5095
GM-Ford
Liquid Line



FMSI #5096
Ford
Springlock

Orifice Tube Installer/Remover



FMSI #5099
All Orifice Tubes



FMSI #5100
Broken Orifice Tube
Remover